A

A-Arm Mount Plate 49
A-Arm Nut Plate 48-49
A-Arm Slug 48
A-Arm Spacer 49
A-Arms 48-50
Accumualtor 186
Adel Clamp 235
Adhesive 251
Adjustable Wrench 274
Air Box 13, 18
Air Box 358
Air Cleaner Nut 216
Air Dam 280
Air Duct Hose 136
Air Filter 215, 358
Air Filter Oil & Cleaner 358
Air Riveter 31
Air Tank 176, 327
Aluminum Sheet 29
Angle Finder 273
Anit-Seize 39, 43, 155, 206
Arm Guard 277
Arm Restraint 260
Assembly Lube 229, 235
Axle Lock Up Plug 157
Axle Nuts (Sprint/Midget) 316-317, 325
Axle Puller 163
Axle Seals 163
Axle Strap 40
Axle Tether 286
Axle Tubes 164
Axles 163, 286

B

Balance Bar Assembly 135
Ball Joint Boot 57
Ball Joint Holder 49
Ball Joint Sleeve 54, 55, 57
Ball Joint Socket 54, 57
Ball Joint Tool 55
Ball Joints 53-56
Batteries 206-207
Battery Box 206-207
Battery Cable 145, 207, 208
Battery Charger 207
Battery Disconnect 208
Battery Tender 207
Battery Terminals 145
Bead Breaker 179, 322-323
Beadlock Bolts 322
Beadlock Rings 173-174
Bearing Spacers 170
Bearings (wide 5) 169
Bell Crank 357
Bellhousings 137, 143, 144
Belts 68, 184
Bircage 101-104
Birdcage Bearing
  Stock Car 103, 105
  Sprint & Midget 318
Birdcage Bracket (sprint) 318
Birdcage Clevis (sprint & midget) 319
Birdcage Insert (midget) 319
Birdcages (sprint & midget) 317-318
Bladders (sprint & midget) 350
Bleeder 175-176, 326
Bleeder (brake) 118, 131, 332, 336
Bleeder Disconnect 326
Bleeder Screens 326
Bleeder Tank 176, 327
Blower (helmet) 258
Bodies & Body Mounting 2-34, 276-279
Body Bolts 32
Body Brace 2, 4, 8, 11, 15, 24, 26-28
Body Savers 34, 279
Body Washers 32
Bolts 35, 36
Brackets 38, 126, 283
Brake Bias Adjusters 135
Brake Bias Panel 131
Brake Blower/Fan 136
Brake Bracket 101, 120, 126, 164, 331-332, 335
Brake Caliper 116-119, 329-330, 332, 335-336
Brake Caliper Orings 118
Brake Caliper Pistons 118
Brake Cleaner 55, 60, 118, 130, 183, 193, 330, 332, 340
Brake Clip 126
Brake Disconnect 135, 330, 338
Brake Duct 18
Brake Duct 136
Brake Duct Hose 136
Brake Fittings 126-129, 243-245, 337
Brake Floater 105, 120
Brake Fluid 131, 338
Brake Kit (sprint) 332
Brake Light Switch 135
Brake Line 125-126, 128, 337
Brake Line Bender 337
Brake Line Bracket 244
Brake Line Clip 244
Brake Line Guard 320
Brake Line Kit (sprint) 338
Brake Master Cylinders 132-133, 339-340
Brake Pad Spacers 336
Brake Pads 121-124, 329, 331-332
Brake Pedals 134, 340
Brake Pressure Gauges 131
Brake Proportioning Valve 130
Brake Residual Pressure Valve 130, 338
Brake Rotor Clamp (sprint & midget) 334
Brake Rotors 113-116, 329-330, 332-333
Brake Shims & Spacers 125
Brake Shut Off Valve 131
Breather (rear end) 311
Breather Tank (crankcase) 185
Breathers (rear end) 155
Breathers (valve cover) 185, 217
Bump Steer Gauge 272
Bump Steer Spacer 58
Bump Steer Stud 58
Bump Stop 75-76, 89
Bumper 7, 12, 16, 21, 281
Bumper Cover 6, 12, 16, 20
Bumper Duct 136
Bumper Mounting 13, 16, 21
Bushing (torsion bar) 301
Bushings (torque link & traction) 107, 112
Bypass (fuel) 355-356
Bypass Checker 359
Bypass Pills 356

C

Cage 1
Caliper Brackets 101, 120, 329
Caliper Orings 118
Caliper Shim 125
Calipers 116-119
Cam Seal Plate 293
Cam Spud 293
Canister Mount 79, 90
Cap (fuel) 228
Cap (power steering) 70
Cap/Rotor 346
Car Covers 273
Carb Fittings 220, 242
Carb Gaskets 218
Carb Hat 216
Carb Line Assemblies 220
Carb Spacers 221
Carb Stud 216, 221
Carburetor Parts 218-219
Carburetors 217-218
Carrier Case 162
Carrier Seal (quick change) 157
Carriers (ford 9") 160
Caster Camber Gauge 273
Center Link 59
Chain Limiter 105
Chassis 1, 275-276
Chromoly Bolts 36
Chromoly Studs 35
Cleaner 2, 4, 9-10, 28, 278, 280, 288, 312
Cleco 33
Cleco Clamp 33
Cleco Tool 33
Clevis 43
Clutch Alignment Tool 141
Clutch Pack 138-140
Clutch Pedal 134-135
Clutch Slave Cylinder 133
Clutches 137-141
Coil Brackets 201
Coil Over Bearing 75, 88
Coil Over Hardware 75-76, 79, 81, 84-85, 88-89
Coil Over Springs 92, 94
Coil Wires 201, 205, 346
Coils 201, 204, 347
Collapsible Steering Column 63-64
Collar Clamp 65
Control Arm (lower) 50-51
Control Arm (upper) 48-50
Control Arm Bushings 51-52
Control Arm Spacers 51
Coolers 69
Cotter Pins 118
Counter Sink Drill Bit 28
Coupler (sprint) 307
Cowl 18
Crank Hub 143-144
Crank Mandrel 183
Crank Trigger 347
Crash Pad 269
Crimp Hose & Fittings 231
Crimper 209
Crush Washers 239, 243-244

D

Dash (sprint) 278
Deck Lid Mount 8, 13
Degreaser 193
Differentials 157
Dimpling Tool (dzus) 34
Distributors 202-203
Distributor Gears 203, 346
Distributor Hold Down 203, 346
Distributor Parts 204
Door Bar 1
Door Bar Pad 267
Door Support 8
Dowel Pin (motor) 302
Drain Plug 186
Drill Bit 28, 31
Drill Bit 171
Drill Block 38
D-Ring Kit 259

Drink Holder 266
Drive Flange 168-169
Drive Flange Bolt Kit 168
Drive Flange Gasket 168
Drive Spud 183
Driveline Checker 305
Driveline Restraint (sprint) 306
Drivers Suit 263
Driveshafts 151
Driveshafts (sprint) 306
Dry Break (brakes) 135, 142
Dry Sump Belts 184
Dry Sump Breather Cans 185
Dry Sump Filters 187
Dry Sump Pulleys 183
Dry Sump Pump Mount 183
Dry Sump Pump Parts 182
Dry Sump Pumps 182
Dry Sump Tank 184
Dry Sump Tank Heater 184
Dry Sump Tank Mounts 302
Duct 18
Duct Tape 39
Durometer 179
Dust Cap & Plugs 241
Dust Cap (sprint) 288
Dust Cap (wide 5) 168
Dzus Buttons 33, 279, 322
Dzus Plate 34, 279
Dzus Springs 34
Dzus Tool 33, 34

E

Ear Buds 267
Electrical Connectors 209
Engine Heaters 343
Engine Oil 189-193
Exhaust Clamps 250, 344-345
Exhaust Elbows 249
Exhaust Tabs 250, 345
Expansion Tank 196

F

Fan Shroud 196
Fan Spacer 197
Fans 196-197
Fenders 23
Fill Plate 228, 351
Filter (helmet) 258
Filter Cleaner & Oil 216
Filters (air) 215-217, 224
Filters (oil) 187-188, 235
Fire Systems & Bottle 270
Firesleeve 234
Firewall Bearing 64
Fitting Wrenches 231, 235
Fittings 71, 126-127, 142, 186, 213, 220-221, 229-234, 236-245, 337, 343, 354, 356
Flaring Tool (brakes) 126
Flashlight 325, 334
Flexplate Bolts 141
Flexplates 141
Flip Pin 30
Floor Pan 279
Flow Valve 67
Flywheel 138-140, 143-144
Flywheel Bolts 139, 141
Frames 1
Front Axle (sprint & midget) 286
Fuel Bypass 355-356
Fuel Cell 227, 350
Fuel Cell Foam 227
Fuel Cell Hose 228
Fuel Filter Bracket 224, 352
Fuel Filters 224, 350, 352
Fuel Jug 228, 354
Fuel Line 221, 229, 234
Fuel Manifold 242, 354-355
Fuel Pickup 228
Fuel Pumps 225-226, 353-354
Fuel Regulator 226, 355
Fuel Shut Off 225, 353
Fuel Treatment 223, 227-228, 351, 354-355, 359

G

Gas Pedal 222-223
Gasket (ford 9") 161
Gasket (fuel cell) 228, 351
Gaskets (quick change cover) 156
Gauge Brackets 278
Gauge Fittings 213, 349
Gauge Grommet 212, 278, 349
Gauge Panels 213, 349
Gauges 212, 348
Gear Bag 265
Gear Oil 153, 165, 312
Gear Totes 158, 312
Gear Tray 158, 312
Gears (quick change) 158-159
Gloves 264, 266, 312
Graphics 12
Grease 44, 55-56, 59, 152, 157, 168, 170-171, 288-289, 301, 304, 307
Grinding Disc 180
Groover 179
Ground Cable 208
Gussett 38

H

Harness Pads 260
Head & Neck Restraint 259-260
Head Support 267
Header Bolts 248, 344
Header Gaskets 248, 344
Header Guard 345, 347
Header Studs 248, 344
Header Wrap 251
Headers 246-247, 344
Heat Mat 251
Heat Paint 40, 251, 345
Heat Sleeves 266
Heat Sleeving 345
Heat Tape 40, 345
Heater (oil tank) 184
Heater Fittings 343
Heater (engine) 343
Heel Riser 279, 340
Helmet 252-255
Helmet Bag 255
Helmet Blower 258
Helmet Hose 258
Helmet Restraint 259
Helmet Shield 255-256
High Speed Checker 359
Honeycomb (radiator) 198, 342
Hood 276-277
Hood Hinge 2, 9, 13, 21, 28
Hood Pin Bracket 7-8, 12, 16, 21
Hood Pin Lanyard 30
Hood Pins 30
Hood Prop 9, 13, 21, 28
Hood Scoop 25
Hose 71, 128, 228-229, 231, 233-234
Hose Clamps 198, 342
Hose Finisher 235
Hub Bearings (sprint) 287
Hub Bearings (wide 5) 169
Hub Nut 169-170
Hub Seal (wide 5) 169
Hub Wrench 169, 287
Hubs (5x5) 169-170
Hubs (sprint front) 287
Hubs (wide 5) 167
Hydraulic Throw Out Bearing 142

I

Idiot Lights 210, 214
Idler Arm 59
Ignition Box 200, 347
Ignition Box Mount 200, 346
Indexing Washers (spark plugs) 206, 347
Inflation Gun 171
Inflation Unit 78, 80, 84-85, 90
Injection Plugs 359
Injection Stack Seals 359

J

Jack Stands 274
Jacobs Ladder 319-320
Jacobs Ladder Pin 320
Jacobs Ladder Springs 320
Jacobs Ladder Strap 319
Jam Nuts 43, 296, 319
Jet Tool 219
Jets (carburetor) 219
Jumper Posts 208

K

Kick Panels 279
Kill Switch 346
King Pin 289
King Pin Bearing Kit 289
King Pin Bushings 289
King Pin Reamer 289
King Pin Shims 289
King Pin Tether 286
Knee Guard 280, 294
Knee Pads 266

L

Lanyard 30
Leaf Spring 98
Leaf Spring Hardware 98
Leak Down Tester 359
Leg Supports 268
Locker Spring 157
Lockers (ford 9") 162
Lockers (quick change) 157
Lower Control Arm 50
Lower Control Arm Bushing 51-52
Lower Control Arm Spacer 51
Lowering Blocks 99
Lug Nut Socket 172
Lug Nut Wrench 172
Lug Nuts 171-172
Lumbar Support 269

M

Magneto 346
Magneto Gear 346
Master Cylinder Return Spring 340
Mat 274
Mater Cylinder 132, 133, 339-340
Minispool 161
Mirrors 270
Mono Balls 45
Motor Mount Spacer 44, 181
Motor Mounts 181
Motor Plate (sprint) 302-303
MSD Mount 278, 346

Index • Index • Index •

Mud Plug/Cover 173-175, 322-323
Mud Scraper 180
Mudd Off 26-27, 280
Mufflers 248, 345

N

NACA Duct (helmet) 258
NACA Ducts 136
Neck Collar 259
Nerf Bars 281
Nine Inch Ford Carrier Case 162
Nine Inch Ford Carriers 160, 162
Nine Inch Ford Gasket 161
Nine Inch Ford Pinion Support 162
Nine Inch Ford Rears 160
Nine Inch Ford Ring & Pinion 161
Nine Inch Ford Spool 161
Nose 6, 12, 16, 20, 22-24, 276-277
Nose Brace 8
Nose Graphics 12
Nose Pad 66
Nose Screen 6, 12 14, 16, 20
Nose Support 23
Nose Wing 284
Nose Wing Cap 285
Nose Wing Clamp 285
Nose Wing Post 285
Nose Wing Strap 284
Nose Wing Trailer Mount 284
Notcher 21
Nozzle Filter 357
Nozzle Plug 357
Nozzle (fire) 270
Nut Kit 37
Nuts 37
Nylon Washer 239

O

Oil (engine) 189-193
Oil (gear) 165
Oil (transmission) 166
Oil Cooler 146, 156, 189
Oil Cooler Pump 156
Oil Filter 187-188, 235
Oil Filter Cutter 188
Oil Filter Mount 187
Oil Pan 186
Oil Pan Filter 235
Oil Tank 184
Oil Tank Brackets 302
Oil Tank Heater 184
Orings (brake caliper) 118
Orings (fittings) 239
Ouick Change Rears 152-153, 155
Overflow Tank 196

P

Panel Clips 34
Panhard Adjuster 111
Panhard Bar 110-111
Panhard Mount 107, 109-110
Pedal Assemblies 134-135
Pilot Bushing 141
Pill Case 356
Pills (bypass) 356
Pinion Mount 107-108
Pinion Nut (ford 9") 162
Pinion Seal (ford 9") 162
Pinion Support 162
Pistons (brake) 118
Pit Socket 172
Pitman Arm 59, 291
Piviot Kit (helmet) 255-256
Plastic 29
Plastic Primer 13, 20, 29
Points Box 346
Power Steering Brackets 69
Power Steering Cooler 69
Power Steering Fitting 71, 243, 293
Power Steering Fluid 60-61, 69-70, 293
Power Steering Lines (sprint) 292
Power Steering Pump 67-68, 226, 292
Power Steering Reservoir 67, 69-70
Power Valve 219
Pre-Filters 185, 216, 358
Proportioning Valves (brake) 130
Pulley 68, 70, 183-184, 226
Punch 26
Pyrometer 178

Q

Quick Change Cover Gasket 311
Quick Change Gear Cover 311
Quick Change Gears 158-159, 313-314
Quick Change Parts (winters) 154, 156-157, 309-310
Quick Disconnect 135, 330, 338
Quick Pin 282
Quickner (steering) 62

R

Rack & Pinion 60-61
Rack Boot 60
Rack Plate 60, 62
Rack Spacer 62, 296
Radiator Air Box 13, 18, 342
Radiator Caps 198, 341
Radiator Hose 197-198, 342
Radiator Mount 198, 342
Radiators 198-199, 341
Radio 259, 267
Radio Box 266
Radius Rod 297
Radius Rod Clips 45
Reamer 57-58, 289, 301
Rear End (ford 9") 160
Rear End (quick change) 152-153, 155
Rear End (sprint) 308-310
Rear End Breather 155
Rear End Cooler 146, 156
Rear End Cooler Pump 156
Rear End Cover 311
Rear End Filter 155
Rear End Saver 311
Reducers (exhaust) 250
Regulators 226
Reservoir 67, 69-70
Residual Pressure Valve (brakes) 130, 338
Rev Limiter 347
Ring & Pinion 157, 161
Ring & Pinion Bolts 157, 161
Ring Gear 138-139, 143
Riser Block 195
Rivet Washer 32
Riveter 31
Rivets 31-32
Rock Screen 198, 280, 342
Rocker Panel 8, 13-14, 16, 21, 23
Rod End Reducers 44, 319
Rod End Seals 44
Rod Ends 41-43, 64, 223, 283, 295-296, 300, 315, 319, 340, 358
Roll Bar Padding 267
Roll Cage 1
Roll Off Pad 272
Roof 23-24
Roof Caps 23-24
Rotor Bolts 330
Rotors 113-116
Rub Rail 9-10, 13, 16, 21, 29

S

Safety Wire 38
Safety Wire Drill Block 38
Safety Wire Pliers 38
Scale Box 272
Scale Cart 272
Scale Ramps 272
Scales 271
Scatter Shield 141
Schraeder Valve 176, 326
Scrub Bag 216, 359
Scuff Plate 30
Seat Belt 260-261
Seat Belt Tab 38
Seat Brackets 269
Seats 268-269
Selenoid
Sending Unit (gauge) 214
Servo 60
Shackle 99
Shift Light 211
Shifter Boot 150
Shifter Bracket (sprint) 315
Shifter Cable 315
Shifter Knobs 150
Shifter Rods 150
Shifter 150
Shock Ends 76, 79, 81, 88
Shock Inflation Unit 78, 80, 84-85, 90
Shock Mount 91, 101-104
Shock Oil 80, 85
Shock Pin 91
Shock Protector 88
Shock Workstation 90
Shock Wrench 73, 78, 80, 84-85, 90
Shocks 72-78, 80-88
Shoes 265
Shoulder Supports 268
Shrink Sleeve 26
Shut Off Valve 225, 353
Silicon 39
Siper 180
Slave Cylinder 133
Slave Cylinder Line 126
Slide Pin 119
Slip Yoke 150
Snouts 164
Spacers 44
Spacers (A-Arm) 49
Spacers (tapered) 290
Spacers (wheel/sprint/midget) 316-317, 324
Spanner Wrench 88, 90
Spark Plug Boots 205, 251, 345
Spark Plug Guard 345, 347
Spark Plug Wires 205
Spark Plugs 206, 347
Speed Nuts 32
Spindle 57-58
Spindle Duct (brake) 136
Spindle Reamer 57-58
Spindles (midget) 289
Spindles (sprint) 288
Spline Grease 168
Spoiler 25
Spoiler Hinge 25
Spools (ford 9") 161
Spools (quick change) 157
Spring 92-94, 98
Spring Bucket 95
Spring Bushing 99

Spring Cup 96-97, 104
Spring Plate 96
Spring Rater 95
Spring Rubber 94-95
Spring Slider 97
Spring Spacer 95
Spring Steel 26
Spring Steel Punch 26
Sprint Body Parts 276-279
Sprint Chassis 275-276
Stagger Gauge 180, 273
Stainless Screen 29
Starter 144-145
Starter Button 210
Starter Button (remote) 145
Steering Arm (spring/midget) 290
Steering Arm Studs 290
Steering Box 60
Steering Column 63-64
Steering Fittings 60, 71
Steering Fluid 60
Steering Gear 291-292
Steering Gear Mount 293
Steering Lines (sprint) 292
Steering Mount 64-65
Steering Pump 67, 68, 292
Steering Pump (sprint) 292
Steering Quick Release 65, 294
Steering Quickner 62
Steering Reservoir 67
Steering Rod End 64
Steering U-Joints 62-63
Steering Wheel 66, 294
Steering Wheel Hook 66
Steering Wheel Pad 66
Steering Wheel Spacer 65, 294
Steering Wheel Tape 40
Stop Watch 273
Strapping 26
Strut Bar 51
Stub 1
Studs 35
Studs (wheel) 171
Support Clamp 235
Sure Seal 215
Surge Tank 196
Sway Bar 99-100
Sway Bar Hardware 100
Switch Panels 209
Swivel Coupler (sprint) 307
Swivel Drive Assembly (sprint) 307

T

Tabs 38, 283, 350
Tach Mounts 278
Tachometer 210-211, 348
Tachometer Brackets 211, 348
Tail Light Graphics 12
Tail Tank 350
Tail Tank Mount 350
Take Up Spring 90
Tap Tube 47
Tape 39-40, 251
Tapered Spacer 44, 290, 296
Taps 47, 296
Tear Off Post 256-257
Tear Offs 257
Tethers (helmet) 259
Teflon Paste 39
Teflon Tape 39
Temp Fitting 213, 349
Thread Locker 39, 155, 157, 161
Threaded Insert 45, 296
Throttle Arm 357
Throttle Linkage 223, 357-358
Throttle Pedal 222-223
Throttle Rod 46-47, 298, 358
Throttle Springs 221-222, 357
Throttle Stop 221, 357
Throw Out Bearing (clutch) 142
Tie Downs 40
Tie Rod End 58
Timing Light 203, 347
Timing Sheet 273
Timing Window 343
Tire Gauge 177, 327
Tire Groover 179, 328
Tire Groover (blades/heads) 179, 328
Tire Marker 175-176, 180, 328
Tire Scribe 272
Tire Siper 180, 328
Tire Softner 178
Tire Stagger Gauge 180
Tire Tape 175-176, 180, 323, 328
Titanium Bolts 35
Titanium Studs 35
Toe In Gauge 272
Toe Plate 272
Tool Tray (nose wing) 284
Top Plate Assembly (fuel tank) 351
Top Wing 282
Top Wing Cap 285
Torque Ball 304-305
Torque Ball Boot 305
Torque Ball Housing 304-305
Torque Ball Seal 303
Torque Link 112
Torque Link Bracket 111-112
Torque Tube 306
Torque Tube Stud 306, 311
Torsion Arm 299-300
Torsion Arm Retainers 298
Torsion Bar 298
Torsion Bushing 301
Torsion Bushing Reamer 301
Torsion Stop Bolt 301
Torsion Stops 300
Track Mat 274
Trailing Arm 106-107
Trailing Arm Bracket 104, 106
Trailing Arm Bushing 43
Transfer Punch 33
Transmission 147-149
Transmission Cooler 146
Transmission Fittings 146, 243
Transmission Fluid 146
Transmission Oil 166
Transmission Parts 147-150
Transponder 267
Tubes (threaded tie rod & radius rod) 45-46, 297
Tubing Cap 38
Tubing Notcher 21, 26
Turn Down 249, 345
Turn Plate 273

U

U-Bolt (driveshaft) 152
U-Bolt (leaf spring) 98
U-Joint (driveshaft) 151
U-Joint (sprint) 303-304
U-Joint (steering) 62
U-Joint Assembly (sprint) 303-304
U-Joint Spring 304
U-Joint Strap 152
Upper A-Arm 48-50
Upper A-Arm Mount Plate 49
Upper A-Arm Spacer 49
Upper Control Arm Bushing 52
Upper Link Brackets 111-112

V

Valance 23-24
Valve Core Tool 175, 180, 323
Valve Cover 185
Valve Cover Breather 185, 217
Valve Cover Hold Down 185
Valve Stem 175, 180, 323
V-Bolt 194
Vent 228
Vent Window 9
Vise Jaw (fitting) 230, 235

W

Warning Lights 210, 214, 349
Washer Kits 37
Washers 32, 37
Water Neck 195
Water Pump 194, 343
Water Restrictors 195
Water Treatment 199, 342
Wax 278
Wear Strip 7, 12, 16, 21, 28
Weather Station 359
Weather Tight Connectors 209, 349
Weight Jack 96
Weight Mount 274
Weld Bung (fitting) 245
Weld In Bung 45
Wheel 173-174, 321-323
Wheel Center (sprint/midget) 324
Wheel Flare 23-24
Wheel Spacer Kit (sprint/midget) 316-317, 324
Wheel Spacers 172
Wheel Studs 171
Wheel Wrench 316-317, 324-325
Window Brace 9
Window Cleaner 4, 28
Window Install Kit 9, 28
Window Net 266
Window Net Mounting Kit 266
Windshield Tearoff 9
Wing Cap 285
Wing Cylinder Wiper 283
Wing Line Kit 283
Wing Post 282
Wing Ram/Cylinder 283
Wing Tree 282
Wing Valve 284
Wings 282, 284
Wire Lock 282
Wire Separators 205
Wrenches 274
Wrenches (fitting) 231, 235

Y

Y-Block (fitting) 242
Yoke 151-152
Yoke (sprint) 303
Y-Pipe 249

Index • Index • Index •

Measuring Quick Change Rear Ends



Note that above figure and corresponding measurements below are for a centered rear.

A	B	C	**Axle** (with spool)
69-5/8	26-1/2	30	38
67-5/8	26-1/2	29	37
65-5/8	24-1/2	28	36
63-5/8	23-1/2	27	35-1/8
61-5/8	22-1/2	26	34-1/8
58-5/8	21	24.5	32-5/8
57-3/8	20.375	23.875	32
55-3/8	19.375	22-7/8	31
52-7/8	18-1/8	21-5/8	29-3/4
49-7/8	16-5/8	20-1/8	28-1/4

Note: With offset rears, your right tube is longer than the left tube. For example a 2" offset rear, the center is moved over 2" to the left making the right side tube 4" longer than the left side tube.

Axle length formulas for Wide-5 rears:

Style of Differential	Left side	Right side
Alum Locker, Triple Track, Gleason	Flange to Flange/2 + 3.6875" - offset	Flange to Flange/2 + 3.6875"+ offset
Lightweight Aluminum Locker	Flange to Flange/2 + 2.9375" - offset	Flange to Flange/2 + 4.9375"+ offset
Aluminum Spool & Steel Spool	Flange to Flange/2 + 3.1875" - offset	Flange to Flange/2 + 3.1875"+ offset

Measuring 9" Ford Rear Ends

The offset of a rearend is determined by how much the pinion is moved left or right from the center of the track width. For an example a rearend with a track width of 64" and a 1" offest would make the distance from the pinion to the right hub face 2" longer than from the center of the pinion to the left hub face (33" RS axle, 31" LS axle).

Note: On a 9" rearend, the axle lengths on a centered rearend are generally 4" different in length. This is due to the offset of 3rd member. The measurement from the pinion to hub face will be equal.



Hub	Track width	LS Axle	RS Axle
GN	62"	29.5"	33.5"
Howe 5X5	62"	31"	35.5"
Wides 5	62"	33"	37"

Index • Index • Index •

Brake Bedding

Bedding is a "real conditions" heat cycle and the final step in preparing the pads for service. All pads, even OE stock replacement parts, will benefit from a proper bedding cycle. Bedding can be done either in the vehicle, or on a special bedding dyno that can realistically duplicate the torque loads, pressure, and temperature that will be realized in the vehicle.

The bedding process is the final "heat cure" for the pads. This final bedding cure differs from an oven heat cure in such that the oven heat cure does not include the pressure, torque, and elevated surface temperatures that are necessary to properly condition the pad for service. New pads must be gradually brought up to temperature and then slowly cooled. If the pads are put into hard service right from the start, damage from fractures or accelerated deterioration due to extreme temperature variations between the surface and the body of the pad can occur. Once the brake system has been tested and determined safe to operate the vehicle, follow these steps for bedding of all pad materials.

1. Begin with a series of 8-10 light stops from approx. 30 MPH down to 15 MPH allowing 20-30 seconds for cooling between each stop.
2. Progress to series of 8-10 moderate stops from around 45 MPH down to 30 MPH allowing a 20-30 second cool down period between each stop.
3. Proceed with a series of 8-10 hard stops from 55-65 MPH down to 25 MPH allowing 20-30 seconds of cool down time between each stop.
4. Drive at a moderate cruising speed, with the least amount of brake contact possible, until most of the heat has dissipated from the brakes. Avoid sitting stopped with the brake pedal depressed to hold the car in place during this time. Park the vehicle and allow the brakes to cool to ambient air temperature.

During the bedding process, a more positive feel from the brakes should develop. This is an indication that the bed in process is working. If any level of brake fade is observed during the hard stops, it may be an indication that the brakes have been more than adequately heated. Begin cooling the brakes with light driving and without brake contact immediately.

Balance Bar Adjusting

The balance bar is an adjustable lever (usually a threaded rod), that pivots on a spherical bearing and uses two separate master cylinders for the front and rear brakes. Most balance bars are part of a pedal assembly that also provides a mounting for the master cylinders. When the balance bar is centered, it pushes equally on both master cylinders creating equal pressure, given that the master cylinders are the same size bore. When adjusted as far as possible toward one master cylinder it will push approximately twice as hard on that cylinder as the other.

To set up the balance bar, thread themaster cylinder pushrods through their respective clevises to obtain the desired position. Threading one pushrod into its respective clevis means threading the other one out the same amount. Sometimes this will lead to a "cocked" balance bar when the pedal is in the relaxed position, Figure 1, no pedal effort. This is acceptable as long as each master cylinder pushrod is completely free of pressure when the pedal is relaxed.



No Pedal Effort | Moderate Pedal Effort | Heavy Pedal Effort

Note: The pushrod adjustment in this figure is representative of a typical ashpalt application that is, large pistons in front, and small pistons in the rear

Figure 1. Balance bar lever adjustment

It is important that the operation of the balance bar functions without interference by over adjustment. This can occur when a clevis jams against the side of the pedal or the lever (bolt) hits the pedal bore during any point of pedal travel, Figure 2. Lever movement should be unimpeded throughout pedal travel. In the neutral position, clevises should have between .20" - .25" total clearance between the side of the pedal. The large washers between the pedal and clevis should remain loose. Make sure that the master cylinder pushrods remain true in relationship to the cylinder during entire pedal travel; pushrods should not be pushing master cylinder pistons at an angle. See Figure 3.



Figure 2. Example of lever interference



Figure 3. Example of pushrod alignment

Note: In its non-depressed position, the pedal and balance bar should allow the pushrod of the master cylinders to fully return. This can be checked by feeling pushrods for very slight movement, not loose movement. Master, cylinder pistons should be against the retaining

Index • Index • Index •

Steering U-Joint Installation



The yokes at opposite ends of any shaft segment should be aligned with their bores parallel, at least within reason. Phasing or "clocking" of the universal joints is especially important when welding u-joints directly to the shaft, since it will be impossible to reposition them once you've done it. Any back-to-back pair should be aligned like the ends of a driveshaft, as in the picture at the right. Please study it closely; the difference is not obvious unless you are looking for it. The more acute the operating angle, the more critical the phasing. At around 45 degrees out of phase, the shaft will react to applied torque with a wobble, with the condition being most pronounced at 90 degrees. A badly out-of-phase setup makes excessive ujoint angles act even worse, and cannot be improved by retiming the steering wheel. For reference, most stock car steering layouts will tolerate joints 20 degrees out of phase, and will not likely cause noticeable problems in steering, but 45 degrees out will be noticeable, and 90° will almost certainly cause problems.

Fitting Sizing Chart

AN Male Sizes



Note: The following chart gives fractional equivalents to hose and dash sizes.
Dash sizes are the numerators of fractions with a denominator of 16.

AN	Fractional Equivalent	AN	Fractional Equivalent	AN	Fractional Equivalent
-3	3/16"	-8	1/2"	-16	1"
-4	1/4"	-10	5/8"	-20	1-1/4"
-6	3/8"	-12	3/4"	-24	1-1/2"

Pipe Threads (NPT)



 California Residents see page 367

Index • Index • Index •

Behling In-House Services

Clutch Inspesction & Repair

Don't miss a lap! Whenever you have the motor out of the car, get the clutch checked. It saves you time, money, and it just makes sense. We can inspect, torque test, and check for release on your clutch. If it works on our test stand it will work in your car. Clutch testing is $25 per unit, except October 1st till December 20th we will offer the clutch testing free of charge. With exception for an extreme emergency we require 2-3days to complete our clutch service. Don't forget to bring in or ship the flywheel with your clutch. Blow the dust and debris off the clutch and reassemble it exactly as it was on the motor, Then bring it in for inspection, test, and repair if necessary.

Typical Inspection includes:

- Spring tension test of clutch cover
- Checking of clutch disc(s), floater plate(s), pressure plate, and flywheel for maximum wear tolerances
- Checking floater plate(s), pressure plate, and flywheel for warping
- Spline wear and fatigue
- Torque test clutch to make sure it meets factory specifications
- Check for smooth and proper release and engagement of clutch to ensure maximum performance

Shock Dyno, Revalve & Repair

Behling Racing Equipment does not offer In-house shock dynoing or rebuilding. We can still meet all of your shocks needs. Call us or drop off you racing shocks and we can have them dyno'd fixed on your behalf.

Spring Testing

Behling Racing Equipment offers In-House racing coil spring testing. Don't doubt your suspension, for only $2.00 (each spring) we can accurately measure the linear rate of most coil springs.

California Proposition 65

What is California Proposition 65?

In 1986, California voters approved an initiative to address their growing concerns about exposure to toxic chemical. That initiative became the Safe Drinking Water and Toxic Enforcement Act of 1986, better known by its name of Proposition 65.

Recent changes to the law have updated the product labeling requirements for product sold in California. Warning labels must accompany any product that contains or may contain any of the chemicals appearing on the list administered by California's Office of Environmental Health Hazard Assessment (OEHHA).

What does this mean for the products in this catalog?

Proposition 65 imposes strict penalties for noncompliance and the list of chemicals is so expansive that it is cost-prohibitive for a small company to go through the individual testing process for each product that is offered. As a result, Behling Circle Track Equipment LLC (Behling Racing) is taking a conservative approach and warning its customers and more specifically the California Residents some if any of the products we sell might fall under the concern of Proposition 65. Again because of the extensive cost involved we are leaving the labeling of each individual product up to the manufacturers discretion. This does not mean that we believe any of the products we sell or distribute are harmful when used as designed.

Behling Racing is committed to the safety and protection of our customers. Although Behling Racing does not manufacture any of the products we sell and/or distribute, some of the products may or may not contain one or more of the listed chemicals in Proposition 65's concern, however we have chosen to issue this warning on all products as an act of extreme caution and because our customers have the right to know.

Warning:
Cancer and Reproductive Harm
www.p65warnings.ca.gov

Additional Resources

For more information about Proposition 65 visit:
https://oehha.ca.gov/proposition-65/general-info/proposition-65-plain-language

California Residents see page 367

Index • Index • Index •

Racer Notes: